



Easy user guide RT500/RT500RF **Programmable Room Thermostat**

NOTE: The RT500RF is time and temperature controlled.



If the unit times out, data will be saved to that point.

SETTING THE TIME AND DAY

To set the clock press and hold the SELECT and SET buttons for 3/4 seconds.

Input correct hour using your up or down buttons, making sure it's on the correct AM or PM.

Now you will see the day flashing. Use the up or down buttons to set the correct day.


Then press SELECT.

Use the up or down buttons to set the correct minutes.

Then press SELECT

Then press SELECT.

and then SET.





Day and time are now set.

PROGRAMMING WEEKDAYS

Press SET and MTWTF will flash (Only in 5-2 day mode).

See manual for alternative mode settings.

Press SELECT key to select first program.

Use up or down buttons to change hour.


Press SELECT and minutes will flash.

Use up or down buttons to change minutes.

Press SELECT and temperature will flash.

Use up or down buttons to change temperature.

Press SELECT and program will move to the next program.



PROGRAMMING WEEKEND

After programming weekdays, press SET and then up arrow key SA SU will flash. Then press SELECT.

Repeat Steps TWO to FOUR as above.



FROST PROTECTION

To enable the Frost Protection mode, press FROST button for 3-4 seconds. Once Frost Protection is enabled, the set point temperature is automatically set to 5°C to provide protection from the risk of freezing.

Whenever Frost Protection is activated, the Frost Protection indicator will flash.

To cancel, press FROST button again for 3-4 seconds.





SLEEP MODE

To enter sleep mode hold the up and down buttons for 3 seconds.

The RT500 functions will be paused to save battery power. To wake the unit up, press any key.





For more information please contact the SALUS technical team Tel: 01226 323961 www.salus-tech.com